


# Zirconium alloys high temperature oxidation laws determination and MFront implementation

Ali Charbal, Thomas Guilbert, Maxence Wangermez, Jean-Christophe Brachet and Thomas Helfer

### Loss Of Coolant Accident conditions (postulated scenario)


#### Pressurized Water Reactor




- Nuclear core generates heating
- Heat is extracted by the water coolant
- Water is pressurized to maintain its liquid state at temperatures ~300°C

### Loss Of Coolant Accident conditions (postulated scenario)

#### Pressurized Water Reactor





### LOCA and consequences on the fuel rods:

Example of a « large break » LOCA scenario.



Breach in the primary circuit, depressurization, loss and vaporization of water coolant ...

Increase of the temperature and internal pressure


Cladding ballooning/burst, blockage rate, fuel pellet relocation and dispersion?

High temperature corrosion and resistance to quenching

Oxidation kinetics and hydrogen uptake, embrittlement?


Post-quench sollicitation


Residual ductility?



### LOCA and consequences on the fuel rods cladding:








### LOCA and consequences on the fuel rods cladding:






### HT Oxidation, effect of Oxygen on Zr phase formation

# 1200


#### Zr phases diagram vs. O at atmospheric pressure

Abriata et al., 1986




- Oxidation temperature will affect the phases formation
- The oxygen concentration will affect the mechanical response of the cladding: ZrO2 et Alpha(O) are brittle

### HT Oxidation, effect of Oxygen on Zr cladding




#### Mechanical response affected by oxygen concentration

Cabrera. PhD Thesis, 2012




- The phases formation need to be quantified → use of metallographic observations and weight gain measurements
- They are correlated to the (post-quench) mechanical testing response to determine the remaining cladding ductility

### HT Oxidation, effect of Oxygen on Zr cladding



#### Representation and observations of the generated phases (post-quenching)


Brachet et al., 2001




- The cladding tube will have a multi-layered structure with Alpha (O), ex-Beta and zircone
- The formed phases post-oxidation are correlated to the oxygen local concentration

### **DEZIROX**, high temperature oxidation kinetics

#### Reference HT oxidation device with more than 2000 realized tests



Brachet et al. ,2001, AIEA Halden




#### **DEZIROX**: HT oxidation

- Heat generated by two ovens : from 700°C to 1250 °C
- Experiments are carried at constant temperature
- Sample suspended in steam environment :
  - Plates
  - One (mostly) or two sided HT oxidation test on cladding
  - Cladding after burst testing on EDGAR
    - → sequenced semi-integral testing
    - → investigation of secondary hydriding mechanism and effects
- Samples are water-quenched or step-cooled

### **DEZIROX**, high temperature oxidation kinetics

Reference HT oxidation device with more than 2000 realized tests



#### Brachet et al. ,2001, AIEA Halden




#### **DEZIROX**: HT oxidation

- Heat generated by two ovens : from 700°C to 1250 °C
- Experiments are carried at constant temperature
- Sample suspended in steam environment :
  - Plates
  - One (mostly) or two sided HT oxidation test on cladding
  - Cladding after burst testing on EDGAR
    - → sequenced semi-integral testing
    - → investigation of secondary hydriding mechanism and effects
- Samples are water-quenched or step-cooled

### I2TOX, high temperature oxidation kinetics

#### **Controlled environment**



Brachet et al., 2020, Corr. Sc.




#### **I2TOX**: Oxydation HT

- Heat generated by two ovens : from 400°C to 1600 °C
- Experiments can be carried at constant temperature or thermal ramps in dynamic conditions (>1°C/s, up to 50°C/s)
- Samples can be suspended to neutral or steam environment:
  - Plate
  - One or two sided HT oxidation on cladding tubes
  - Cladding after burst testing on EDGAR
- Controlled steam flow rate
- Samples can be quenched by air or water

### I2TOX, high temperature oxidation kinetics

#### **Controlled environment**



Brachet et al., 2020, Corr. Sc.




#### **I2TOX : Oxydation HT**

- Heat generated by two ovens : from 400°C to 1600 °C
- Experiments can be carried at constant temperature or thermal ramps in dynamic conditions (>1°C/s, up to 50°C/s)
- Samples can be suspended to **neutral or steam** environment:
  - Plate
  - One or two sided HT oxidation on cladding tubes
  - Cladding after burst testing on EDGAR
- Controlled steam flow rate
- Samples can be quenched by air or water

### CINOG-HP, high temperature oxidation kinetics

#### **Effect of external pressure**




Le Saux et al., 2014, ASTM



#### **CINOG: Oxydation HT**


- Heat generated by induction : from 400°C to 1550 °C
- Steam (external) pressure can be raised up to 80 bars
- Experiments are usually carried at constant temperature
- Sample suspended in steam environment:
  - Plates
  - Two sided cladding HT oxidation testing
- Monitored and controlled temperature by IR pyrometers
- Samples can be water-quenched

### HT Oxidation, phases distribution quantification




#### **Observations of the generated phases (post-quenching)**

Cabrera. PhD Thesis, 2012




470 s 1100°C



1500s 1200°C


- The mass gain (g/cm2), ZrO2 and Alpha(O) thicknesses (μm) can be measured after each oxidation tests
- Parabolic correlations can be determined as a function of the oxidation temperature (T) and duration (t)

### HT Oxidation, parabolic time dependences



#### Weight gain

Portier et al. 2005, ASTM



#### **Example of the mass gain**

$$(gdm)^n = \left(\frac{m}{S}\right)^n = K^{gdm}.t$$

gdm: mass gain expressed in (kg/m²)<sup>n</sup>

m : mass (kg)

S : exposed surface (m<sup>2</sup>)

t : time (s)

n : 2 (depends on the oxidation regim)

$$K^{gdm} = K_p^{gdm_o} \cdot \exp\left(-\frac{E_a}{RT}\right)$$


 $K_p^{gdm\_o}$  : constant parameter  $(kg^n.m^{-2n}.s^{-\frac{1}{n}})$ 

 $E_a$ : activation energy  $(J mol^{-1})$ 

T : Temperature (K)


R : 8,314  $(J K^{-1} mol^{-1})$ 

### HT Oxidation, parabolic time dependences



#### Oxide layer thickness

Grosse et al. 2010



#### **Example of the ZrO2**

$$(e_{\underline{z}r02})^n = K^{\underline{z}r02}.t$$

ZrO2: Thickness (m *or μm*)

t : Time (s)

n : 2 (depends on the oxidation regim)

$$K^{ZrO2} = K_p^{ZrO2\_o} \cdot \exp\left(-\frac{E_{a-ZrO2}}{RT}\right)$$

 $K_p^{\mathbf{Z}r\mathbf{0}\mathbf{2}\_o}$ : Constant parameter  $(m^n. s^{-\frac{1}{n}})$ 

 $E_{a-\mathbf{Z}r\mathbf{02}}$ : Activation energy  $(J \ mol^{-1})$ 

T : Temperature (K)


R :  $8,314 (J K^{-1} mol^{-1})$ 

### **HT Oxidation, Mfront Implementation - description**



```
@DSL Model;
@Model CP1977 HighTemperatureOxidationModel;
@Material Zy4;
@Author
       Thomas Guilbert / Maxence Wangermez / Thomas Helfer / Ali Charbal;
@Description{Oxidation laws describing the Zy4 cladding alloy: mass gain, Alpha(0) and ZrO2 thicknesses
evolution identified by CATHCART-PAWEL
Remark
                  : parameters were adapted in order to use the physical constant R = 8.314 J K-1 mol-1
                           Mass gain unit : kg / m2 - SI unit
                           Thickness unit : m - SI unit
                           Thickness unit : m - SI unit
                           Allov
                                             : Zv4
                           Temperature range : 1000 - 1500
                  : Cathcart, J.V., Pawel, R.E., McKee, R.A., Druschel, R.E., Yurek, G.J., Campbell, J.J., &
Reference
Jury, S.H. (Jul 1977). Zirconium metal-water oxidation kinetics IV Reaction rate studies (ORNL/NUREG--17).
United States "https://www.nrc.gov/docs/ML0522/ML052230079.pdf"};
```

### HT Oxidation, Mfront Implementation – Output/Input



### **HT Oxidation, Mfront Implementation - Models**

```
// Mass gain parameters - T 1000 - 1500 °C
@Parameter quantity<real, 2, -4, -1> K0_gdm = 3.62e+1;
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea_gdm = 167116.0;
// Parameters for the Alpha(0) thickness - T 1000-1500 °C
@Parameter quantity<real, 0, 2, -1> K0 AlphaO = 1.53e-4;
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea_Alpha0 = 201428.0;
// Parameters for the the ZrO2 thickness - T 1000-1500 °C
@Parameter quantity<real, 0, 2, -1> K0_ZrO2 = 2.25e-6;
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea_Zr02 = 150170.0;
@Function CP1977 HighTemperatureOxidationModel{
 constexpr auto R = PhysicalConstants::R;
 const auto T mts
                        = (T + T 1) / 2;
 const auto
              К1
                        = K0 gdm * exp(-Ea gdm / (R * T mts));
                        = power<1,2>(gdm_1 * gdm_1 + K1 * dt);
              gdm
 const auto
              К2
                        = K0_AlphaO * exp(-Ea_AlphaO/ (R * T_mts));
              eAlpha0
                        = power<1,2>(eAlpha0 1 * eAlpha0 1 + K2 * dt);
 const auto
              К3
                        = K0 Zr02 * exp(-Ea Zr02 / (R * T mts));
                        = power<1,2>(eZrO2 1 * eZrO2 1 + K3 * dt);
              eZrO2
```

### HT Oxidation, Mfront Implementation - description


```
@Model CP1977 HighTemperatureOxidationModel;
@Material Zv4:
@Author Thomas Guilbert / Maxence Wangermez / Thomas Helfer / Ali Charbal;
@Description{Oxidation laws describing the Zy4 cladding alloy : mass gain, Alpha(0) and ZrO2 thicknesses evolution identified by CATHCART-PAWEL
                   : parameters were adapted in order to use the physical constant R = 8.314 J K-1 mol-1
                                                                  Mass gain unit : kg / m2 - SI unit
                                                                  Thickness unit
                                                                                                                 - SI unit
                                                                  Thickness unit
                                                                                                 - SI unit
                                                                                     : Zy4
                                                                  Temperature range : 1000 - 1500
                  : Cathcart, J.V., Pawel, R.E., McKee, R.A., Druschel, R.E., Yurek, G.J., Campbell, J.J., & Jury, S.H. (Jul 1977). Zirconium metal-water oxidation kinetics IV Reaction rate studies (ORNL/NUREG--17). United
States "https://www.nrc.gov/docs/ML0522/ML052230079.pdf"};
@Output real gdm;
gdm.setEntryName("MassGain");
gdm.setDepth(1);
@Output length eAlphaO;
                                                                                                                                                                                                Isotherme Palier 1200:CATHCART, AWEL 700 à 1400 °C
eAlphaO.setEntryName("AlphaOLength");
eAlphaO.setDepth(1);
                                                                                                                                                           Analytique
                                                                                                                                                          MTest
@Output length eZrO2;
                                                                                                                                                            -Temperature
                                                                                                                                                                                                                            1400
eZrO2.setEntryName("ZrO2Length");
eZrO2.setDepth(1);
@Input temperature T;
                                                                                                                                                                                                                            1200
T.setGlossaryName("Temperature");
                                                                                                                                                   0.25
T.setDepth(1);
@PhysicalBounds T in [0 : *[;
                                                                                                                                                                                                                           1000 🕤
@Bounds T in [1273.15 : 1773.15];
                                                                                                                                                 (kg/m2)
                                                                                                                                                    0.2
                                                                                                                                                                                                                           800
// Mass gain parameters - T 1000 - 1500 °C
                                                                                                                                                 ₩
0.15
@Parameter quantity<real, 2, -4, -1>
                                                K0_gdm = 3.62e+1;
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea gdm = 167116.0;
                                                                                                                                                                                                                           600
// Parameters for the Alpha(0) thickness - T 1000-1500 °C
@Parameter quantity<real, 0, 2, -1>
                                              K0 Alpha0 = 1.53e-4:
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea_AlphaO = 201428.0
                                                                                                                                                     0.1
                                                                                                                                                                                                                           400
// Parameters for the the ZrO2 thickness - T 1000-1500 °C
                                              K0_{Zr02} = 2.25e-6;
@Parameter quantity<real, 0, 2, -1>
@Parameter quantity<real, 1, 2, -2, 0, 0, 0, -1> Ea_ZrO2 = 150170.0;
                                                                                                                                                   0.05
                                                                                                                                                                                                                           200
@Function CP1977_HighTemperatureOxidationModel{
 constexpr auto R
 const auto
               T mts
                          = (T + T 1) / 2;
                                                                                                                                                                500
                                                                                                                                                                         1000
                                                                                                                                                                                   1500
                                                                                                                                                                                           2000
                                                                                                                                                                                                               3000
                                                                                                                                                                                                                        3500
                           = K0 gdm * exp(-Ea gdm / (R * T mts));
 const auto
                                                                                                                                                                                    Temps (s)
                           = power<1,2>(gdm_1 * gdm_1 + K1 * dt);
 const auto
                           = K0 AlphaO * exp(-Ea AlphaO/ (R * T mts));
                eAlpha0 = power<1,2>(eAlpha0 1 * eAlpha0 1 + K2 * dt);
  const auto
                           = K0_ZrO2 * exp(-Ea_ZrO2 / (R * T_mts));
                          = power<1,2>(eZr02_1 * eZr02_1 + K3 * dt);
```




## Integrating "LOCA material laws" into ALCYONE MFront bridges the "gap" between various experts



#### **ALCYONE**: fuel performance code






#### **Few ALCYONE features**

- Multiphysics partitioned scheme
- Multiscale modelling
- From 1D to 3D modelling
- From nominal to postulated accidental scenario
- Integrates a large number materials behaviour





### Thank you for your attention